

Daily

- Clean up right after a spill using a damp cloth with warm soapy water and dry it after.

Check for expired items as these may create odors.
- Remove shelves that are dirty or had an expired item on them and wash them in warm soapy water.

If there is an odor, sprinkle baking soda and coffee grounds into a pan and place in the fridge for 24 hours.

Bi-Weekly

- Dump any unused ice to prevent it from clumping or tasting bad
- Use the ice along with some lemon juice to clean your garbage disposal.

Monthly

- Clean the exterior of your fridge with a damp cloth.

Use stainless steel polish and wipe along the grain of the surface (for stainless steel fridges).
- Check for spills, crumbs, or other messes on the inside.

Wipe the screen on your fridge with a microfiber cloth and screen cleaning solution.

Every 6 months

Change the water filter and always use Samsung brand filters.

Date Changed

Date Changed

Date Changed



Filter change due

Filter change due

Filter change due



Yearly

- Deep clean your fridge by removing all the shelves, drawers, and bins and wash them with warm, soapy water.

Clean the inside of the fridge with a damp cloth and warm soapy water. Let it dry.
- Wipe down the rubber seals around the doors.

Slide the fridge out from its spot and clean behind it, and wipe the dust off the back.

